


## GENERAL DESCRIPTION



# THE SPACE SAVER

An easily assembled, structurally strong pocket door frame. Designed for the builder or do-it-yourselfer. Provides a space saving opportunity while still assuring privacy. Pocket doors do not need 'swing' room to use valuable floor space.


Tricycle hangers provide smooth rolling action and are **GUARANTEED** jump proof. Unique design of floor brackets allow for settling of floor without distorting header track.

Available for all standard door sizes, or an all-purpose size to minimize inventory.

**NOTE:** The 1500 Series Frame is available for custom doors up to 5'0" wide; 9'0" high; and up to 200 pounds in weight.


Single packed ready for installation in rough opening

## EXCEPTIONAL FEATURES



### STRONG STIFFENERS

Split jamb and stud uprights have full steel sides and backs to provide maximum rigidity for wall material and restricts nails from penetration into pocket. Slots allow room for easy nailing of trim stops.




### REMOVABLE TRACK

Track has keyhole slots for easy removal without tearing out walls. Box design prevents rollers from jumping track. Convex rails provide one-point wheel contact for smoothness — dirt traps for free rolling.



### TRICYCLE HANGERS

Tri-design insures all wheels carry weight equally. Smooth rolling, balanced wheels ride with minimum friction on convex track rails. A 'flip-of-a-clip' separates hangers from doors for easy door removal.



### \*SELF-ADJUSTING FLOOR ANCHORS

Long vertical fingers slide into split studs — allow for settling of floor without disturbing horizontal alignment of header and track. Plates can be nailed or cemented to floor.

\*NOTE: 1-3/4" doors require Pt. No. 1575 Adaptor Kit. See OPTIONAL listing.


**Johnson**  
HARDWARE  
MOUNTED TRACK  
TRICYCLE  
HANGERS  
COMPACT

**POCKET  
DOOR  
FRAME**

For  
1-1/8" To 1-3/4"  
Doors  
(Max. wt.  
125 LBS.)

**SERIES 1500**

## COMPLETE WITH SCREWS AND INSTRUCTIONS




No. 1500  
FRAME

No. 100  
TRACK  
(Attached to header)



(2 ea)  
No. 1120  
TRICYCLE  
HANGERS  
(1" DIA. WHEELS)

No. 1550  
DOOR GUIDES




No. 1513  
DOOR BUMPER



No. 1712  
ADJ. WRENCH



## OPTIONAL HANGER



**1125**  
For doors  
to 200 lbs.

Ball Bearing wheels provide smooth, quiet, easy operation of very heavy doors. Need no lubrication.

**POCKET DOOR FRAME**


For 1-1/8" To 1-3/4" Doors (Max. wt. 125 LBS.)

**SERIES 1500**

**Cutting Instructions- Johnson Hardware Pocket Door Frame header**

2'6" (76.2cm) and 3'0" (91.4cm) Universal Johnson Pocket Door Frames are marked for cutting to shorter lengths. See cutting instructions below.

1. Remove Adjustable End Bracket.



2. Cut through WOOD part of header only, on desired door size marking. DO NOT CUT TRACK.

3. Turn Header over and cut Track 1 3/8" (35mm) shorter than wood Header.



4. Replace Adjustable End Bracket on new cut end of header.  
5. Turn Header on side and cut 3/4" (19mm) Head Trim Board ONLY at proper mark, remove cut off end and discard.




6. Turn Header and cut off other side.

**Pocket Door Accessories**

**Measure Door Width and construct Rough Opening**  
**Rough Opening Size Chart**


| FOR 1 1/8" TO 1 3/4" DOORS | ROUGH OPENING WIDTH X HEIGHT |
|----------------------------|------------------------------|
| 2'0" x 6'8"                | 49" x 84 1/2"                |
| 2'4" x 6'8"                | 57" x 84 1/2"                |
| 2'6" x 6'8"                | 61" x 84 1/2"                |
| 2'8" x 6'8"                | 65" x 84 1/2"                |
| 3'0" x 6'8"                | 73" x 84 1/2"                |

\* All purpose-marked for cutting to other standard widths  
\*\* 1575 ppk3 1 3/4" adaptor required.




1. Header must be SQUARE and PLUMB with studs and LEVEL.


Mark each side jamb and drive a flat head nail on centerline, leaving 1/8" (3.2mm) protruding. (Frame header end plates will rest on these nails.)



2. Snap two chalk lines on floor even with side jambs as shown.



3. Slip slots in Frame Header End Plates Over nails in side jambs.



4. Slip fingers on Floor Plates into the reinforcing strips of Split Jambs as show. Butt split jambs against header nailer strips and nail in place.



5. Apply desired wall materials over the pocket side and above the door opening. Wall materials are brought clear to the edges of the opening.


**GENERAL INSTALLATION**



6. Seal all edges and face of door panel with choice of paint or sealing stain.



7. Fasten bumper on back edge of door, 40" from bottom edge.




8. Insert hanger wheels into track through space between end plate and track. Fasten hanger plates in place.



9. Hold door in opening and slip pivot pin into slot in plate. Lock in place with locking tab. Adjust hangers for height and plumb with jambs.



10. Use #1510 or #1511 jamb kit and install finished jambs, split header and casing as shown. Fasten finish header on hanger locking or adjustment side with screws so future door removal or hanger adjustments can be made easily.



11. Fasten #1550 Guides on finished split jambs at door bottom so door is held in center of opening without binding.